


# EtherNet/IP SETUP w/ ARLYN UPSCALE



**Platform Cable** – Connects the PLATFORM to the INDICATOR through an M12 Cable.

**Indicator & Platform** – Components that make up your scale.

**Scale Power Supply** – Connects the INDICATOR to your power outlet at 5VDC. Supplies power to the Scale (Display & Platform),

**EtherNet/IP Module** – EtherNet/IP box that converts weight data from the scale to EtherNet/IP Protocol,

**EtherNet/IP Power Supply** – Powers up the EtherNet/IP Module at separately.